

REMOTE STATUS INDICATOR MODEL ASI-02



REMOTE STATUS INDICATOR WITH LAMPS
150 x 465 x 175 (H x W x D)

The lamps indicate “READY”, “MEASUREMENT IN PROGRESS” AND “MEASUREMENT OVER” , using the relay outputs of the Model AUP-500. These indications are of great help to the operator, as they indicate whether the thermocouple is properly inserted into the lance before taking a reading and also whether the reading was completed without thermocouple burn out; in case the thermocouple becomes open before the sampling process is complete “Measurement Over” will not be indicated